



ATF15xx CPLD ISP Software - ATMISP

Contents & Installation Instructions

I. Contents:

1. ATMISP7_setup.exe - Installation executable for ATMISP v7.x.
2. QSTutor.pdf - Quick Start Tutorial for ATMISP v7.x using ATF15xx-DK3 CPLD Development/Programmer board and ATDH1150USB JTAG ISP cable.
3. Readme.pdf - This README file.

II. Installation Instructions:

NOTES:

- ATMISP cannot be installed onto a network drive. It can only be installed onto a local hard drive.
- **ADMINISTRATOR PRIVILEGES** are required to install ATMISP.
- All previous versions of ATMISP must be un-installed before installing this version.
- It is recommended to install ATMISP into the default directory [C:\ATMISP7].
- If ProChip Designer is also installed, it will use this version of ATMISP instead for the "Atmel-ISP" step.

1. Double-click on **ATMISP7_setup.exe** in Windows Explorer to start the installation process.
3. Follow the instructions in Setup Wizard throughout the installation process. The installation of the FTDI USB drivers is required.
4. After the installation is completed and before launching ATMISP for the first time, connect the ATDH1150USB cable to the PC's USB port to complete the installation of the USB drivers.
5. Review Quick Start Tutorial. In the main ATMISP window, go to Help → Quick Start Tutorial. This Tutorial will introduce you to the features of the ATMISP software.

PLD Technical Support:

Email - pld@microchip.com
Online Support - www.microchip.com/technical-support