

---

## Atmel ATF15xx CPLD ISP Software - ATMISP Contents & Installation Instructions

---

### I. Contents:

1. ATMISP7\_setup.exe - Installation executable for ATMISP v7.x.
2. QSTutor.pdf - Quick Start Tutorial for ATMISP v7.x using ATF15xx-DK3 CPLD Development/Programmer board and ATDH1150USB JTAG ISP cable.
3. Readme.pdf - This README file.

### II. Installation Instructions:

1. Un-install all older versions of ATMISP from the PC if one exists.
2. Double-click on **ATMISP7\_setup.exe** in Windows Explorer to start the installation process.
3. Follow the instructions in Setup Wizard throughout the installation process. The installation of the FTDI USB driver through this installation process is highly recommended.
4. After the installation is completed and before launching ATMISP for the first time, connect the ATDH1150USB cable to the PC's USB port to complete the installation of the USB drivers.
5. Review Quick Start Tutorial. In the main ATMISP window, go to Help → Quick Start Tutorial. This Tutorial will introduce you to the features of the ATMISP software.

---

### PLD Technical Support:

Email - [pld@atmel.com](mailto:pld@atmel.com)

Hotline - 1-408-436-4333

Online Support Form - <https://secure.atmel.com/design-support/>

Product Information - <http://www.atmel.com/products/other/spld-cpld/default.aspx>