


HANDHELD PROGRAMMER CONNECTOR (AVR-JTAG MODE)



TOP VIEW OF THE CONNECTOR ON
THE **PROGRAMMER**

This is not end of 10-way lead

TRST Pin is not available

All GND Pins MUST be connected

0.1" PITCH 2*5 BOXHEADER
WITH POLARISING NOTCH

ATMEL JTAG CONNECTOR



TOP VIEW OF THE CONNECTOR
ON TARGET BOARD

0.1" PITCH 2*5 MALE BOXHEADER
WITH POLARISING NOTCH