

TARGET CONNECTOR FOR AVR PROGRAMMERS

MOSI	1	2	VCC
LED OPTIONAL	3	4	GND
RESET	5	6	GND*
CLK	7	8	GND*
MISO	9	10	GND

TOP VIEW OF THE CONNECTOR ON THE TARGET SYSTEM

0.1" PITCH 2*5 BOXHEADER
WITH POLARISING NOTCH

* These pins are not connected to GND by the programmer - they need to be connected to GND on the target for correct operation

